


INSTALLATION QUICK GUIDE

Below are the minimum space and installation requirements for the Boost 2.



Installation Checklist:

Electrical

- For Boost 2 Core: I have a 110V / 120V 20A single phase dedicated circuit.
- For Boost 2 Elite: I have a 208V / 220V / 240V 20A single phase dedicated circuit.

Space

- The ceiling is at least 24 in. higher than tallest user.
- The room is at least 10.5 ft. x 5.5 ft.
- The doorway(s) to entry is/are at least 44 in. wide.
- The doorway(s) to entry is/are less than 44 in. wide.

Delivery/Entry

- I have a loading dock or a forklift for delivery.